

Feature Codes

*50	Disable Call Waiting	For all subsequent calls
*51	Enable Call Waiting	For all subsequent calls
*67	Block Called ID	Per Call Dial *67 + number no dial tone will play in the middle
*82	Send Caller ID	Per Call Dial *82 + number No dial tone will play in the middle
*69	Call Return Service	Dial *69 to call back the last incoming phone number received
*70	Disable Call Waiting	Per Call Dial *70 + number No dial tone will play in the middle
*71	Enable Call Waiting	Per Call Dial *71 + number No dial tone will play in the middle
*72	Unconditional Call Forward	Dial *72 and then the forwarding number followed by #. Wait for dial tone and hang up (dial tone indicates successful forward).
*73	Cancel Unconditional Call Forward	To cancel 'Unconditional Call Forward', dial *73, wait for dial tone, then hang up.
*74	Enable Paging Call	Dial *74 and then the destination phone number you want to page.
*78	Enable Do Not Disturb	DND. When enabled, incoming calls are rejected
*79	Disable Do Not Disturb	DND. When disabled, incoming calls are accepted
*90	Busy Call Forward	Dial *90 and then the forwarding number followed by the #. Wait for dial tone then hang up.
*91	Cancel Busy Forward	To cancel 'Busy Forward', Dial *91, wait for dial tone, then hang up.
*92	Delayed Call Forward	Dial *92 and then the forwarding number followed by #. Wait for dial tone and then hang up.
*93	Cancel Delayed Call Forward	To cancel 'Delayed Call Forward', dial *93, wait for dial tone and then hang up.
	Flash/Hook	Toggles between active call (call waiting tone). If not in conversation, flash/hook will switch to a new channel for a new call.
#	Re-Dial	Pressing pound sign will re-dial the last number called